

## BASS TRAP CORNER IMPALING BRACKETS

MetroFlex Bass Trap Corner Impaling Brackets are designed for fast and easy installation of Bass Trap panels in corners. Low Frequency sound waves (bass) tend to build up in the corners of a room, which makes cutting the corner with a bass trap extremely beneficial for overall sound quality.

Bass Trap Corner Impaling Brackets are made out of heavy galvanized steel and are bent on a 45° angle with two 1 inch impaling prongs on each bracket. Once the brackets are installed onto the walls, the Bass Trap panel (fiberglass or mineralwool) are pressed onto the large impaling prongs which hold the panel securely.

### Recommended Installation


For a standard 24" wide trap, measure out from the corner of the wall 16-3/4" and make a mark on both walls at the height of your trap.

Use a level in between the two marks to adjust the marking to ensure the brackets will be level with each other.

Place the bracket so the prongs are facing up and the non-prong side is flush against the wall. The mark on the wall should be lined up with the front of the bracket (the bend of the bracket). Use screws or drywall expansion screws (if not on a stud) in the two pre-drilled screw holes on the non-prong side.

Repeat the above steps for the bottom two brackets which is approx 40" from the top brackets (48" long trap).

With the use of a level, press the bass trap panel into all 4 of the impaling brackets and slightly press downward.



### Packaging Information

8 Brackets / Box  
(4 Left & 4 Right)

### Corner Bracket Dimensions

6" x 2-1/4" Base  
(Bent in Middle)  
2 Angled Spikes (1" Long)  
2 Fastener Holes



- Time To Cut Corners -

[www.MetroFlexSound.com](http://www.MetroFlexSound.com)